ACCUREX[™]

Direct Gas Make-Up Air Quick Start Guide - Pilot Ignition ≤ 400 mbh

This guick start document is intended to help with getting the initial unit startup completed, but does not replace the IOM. Please read the IOM for all safety information and precautions before performing any work on the equipment. Complete pre-start checks and blower start-up prior to this procedure.

Pre-Start Information: To energize the unit control circuits **Outer Sensing Probes** (field-wiring shown on diagram with dashed lines): a. Exhaust fan (optional) - Connect terminals R to H b. Supply fan - Connect terminals R to G c. Heating - Connect terminals R to W1 d. Cooling (optional) - Connect terminals R to Y1 Pressure Switch 1. Energize the supply fan by connecting terminals R to G. 2. Verify blower rotation is correct. a. To reverse the rotation on three phase units, disconnect and lock out the power, U-Tube Manometer then interchange any two power leads going to the motor. b. Check motor amp draw and compare to motor nameplate FLA reduce airflow if amp draw is greater than FLA. Fig. 1 Measuring the Pressure Drop 3. Check burner pressure differential. (Fig. 1) a. Connect manometer to outer sensing probes Remove one wire to Remove cap to access send the unit to the b. Should be between 0.6-0.7 in wa for natural gas and 0.8-0.9 for LP. maximum firing rate minimum firing rate c. To increase the differential pressure, decrease the burner baffle opening evenly adjustment or increase airflow. d. To decrease the differential pressure, increase the burner baffle opening evenly Pilot Pressure or decrease airflow. Adjustment (LP) Verify the unit inlet gas pressure: a. Inlet gas pressure needs to be equal to or greater than the "minimum for Minimum maximum output", but not to exceed the "maximum gas pressure" listed on the firing rate unit gas pressure label. adjustment 5. Verify inlet air sensor (TS4) setting is set above outside air temp (if equipped). If unit has microprocessor, verify heating lockout setting. Fig. 2 Separate Regulator and Energize the heating by connecting terminals R to W1. If unit has microprocessor, **Modulating Valves** enable heat by setting heat control to 1%. 7. Check pilot flame signal. a. Close main hand valve. b. LP only: Connect manometer to pilot test port. Energize fan; zero manometer; energize heat; adjust pilot pressure to 0.5 in. wg. Natural gas pilot pressure is preset at factory. (If not using digital manometer, see IOM for further details on pilot differential for LP). c. Measure flame current with pilot valve lit and without main gas flowing. d. Set meter to µA DC scale. e. Locate flame signal terminals on BASO ignition control, place red lead on [+] terminal and black lead on [-] terminal. (Fig. 3) f. Recommended minimum pilot only flame sense current of 1 µA DC. 8. Open main hand valve and then set maximum firing rate to the design temperature rise located on the direct gas nameplate. (Fig. 2) a. Send unit to high fire by removing wire connected to terminal 3 of Maxitrol 14/44 amplifier. (If equipped with the SC25 Amplifier, connect terminals T1 and T2). Fig. 3 BASO Ignition b. While measuring temp rise, adjust combo valve regulator to achieve desired Control temperature rise. (Temp rise = discharge temp - inlet temp)

- 9. Set the minimum firing rate to achieve a small ribbon of continuous blue flame across the burner. (Fig. 2)
 - a. Disconnect one of the wires going to the modulating valve and isolate.
 - b. Set the minimum firing rate by adjusting the minimum firing rate adjustment on the modulating valve.
 - d. Cycle the heat to make sure the burner can light at this low fire setting.
- 10. Remove power to terminal W1 to remove the call for heat. Reconnect wires to Maxitrol amplifier and modulating valve.

Installation, Operation





and Maintenance Manual

Direct Gas-Fired Start-Up Video

Pilot Ignition ≤ 400 mbh Quick Start Guide, Rev. 6, April 2018

